

VI.5.3D-SYSTEM-HISTUNIT PROGRAM FCST HCL TECHNIQUE HISTUNIT

Purpose

Technique HISTUNIT sets the unit number range for the ESP Historical Calibration Data Files.

Valid values are NO (0) and YES (1).

The Global default is YES (1).

This Technique is Universal.

Form of Input

HISTUNIT espfile1 espfile2

where espfile1 is the first unit number
espfile2 is the last unit number

Example

HISTUNIT 37 39

Unit numbers 37 through 39 will be used for the ESP Historical Calibration Data Files.